



DESIGN <i>gp</i>	DRAWN BY <i>gp</i>	DART AEROSPACE LTD HAWKESBURY, ONTARIO, CANADA	
CHECKED <i>#</i>	APPROVED <i>#</i>	DRAWING NO. DSI 9329	REV. A SHEET 1 OF 1
DATE 06.04.25		TITLE BUBBLE WINDOW INSTALL MOD.	SCALE NTS
A	06.04.25	NEW ISSUE	

DART SERVICE INSTRUCTION
TO AMEND INSTALLATION INSTRUCTIONS IIN-D044-713 REV. A
REF. CANADIAN STC: SH05-13 ISSUE 1
REF. FAA STC: SR02088NY


PURPOSE: For the D044-713-013/-014 kits supplied after B26748, the D3269-1/-2 bubble windows have been supplied untrimmed to allow for easier installation in the field. The installer must trim the windows in accordance with these instructions prior to installation.

PROCEDURE:

- 1) Modify the R44 crew door per items 3.2.1 and 3.2.2 of Installation Instructions IIN-D044-713 Rev.A.
- 2) Fit and trim the D3269-1/-2 Bubble Window to match the cutout in the door as follows: The bubble window must be a minimum of 0.30" (7mm) larger than the cutout in the OEM window as shown in the figure below. However, in the corners of the window, it is acceptable to trim a 0.06" minimum overlap (1.5mm) to help prevent the D2126-0903 Seal from buckling/creasing in the corners. The edge of the bubble window must be deburred to a smooth finish.
- 3) Continue installing the bubble window per items 3.2.3 through 3.2.5 of the installation instructions.

FIGURE 1


LOOKING AT INSIDE CORNER OF DOOR



SECTION A-A

(NOT TO SCALE)

OUTBOARD



CANADA
DEPARTMENT OF TRANSPORT
AIRCRAFT CERTIFICATION
BRANCH
DAO # 01-O-01

APPROVED

BY: *D. Shepherd*
D. SHEPHERD (DE # 02)

DATE: 06.04.25
CERT. NO.: SH05-13
ISSUE NO.: 1

Copyright © 2006 by DART AEROSPACE LTD

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.